



Pacific Performance Engineering  
303 N Placentia Ave.  
Fullerton, CA 92831  
www.pacificp.com

Technical Support: (714) 985-4825  
Fax: (714) 985-9907  
Email: sales@pacificp.com

## LB7 Increase Valve

### Install Guide

#### Parts Identification



1) Lift up air resonator cover and locate the hose that connects the wastegate and the turbo. Figure 1. shows the hose highlighted in yellow.



Figure 1



Figure 2

2) Cut about 3/4 of an inch off the center of the hose just in front of the turbo so as to fit the Boost Increase Valve.



Figure 3

3) Located on the Boost Increase Valve are arrow markings. The arrows MUST point towards the wastegate which is shown above in Figure 3.

4) Install the clamps on each side of the Boost Increase Valve. Figure 4 shows a complete installation of the Boost Increase Valve.



Figure 4