2002 Ford F-250 SUPER DUTY PICKUP

Submodel: | Engine Type: V8 | Liters: 7.3

Fuel Delivery: FI | Fuel: DIESEL

SECTION 308-07A: Four-Wheel Drive Systems REMOVAL AND INSTALLATION

2002 F-Super Duty 250-550/Excursion Workshop Manual Procedure revision date: 05/23/2001

Gearmotor Encoder Assembly


Material

Item
Multi-Purpose Grease
XG-4 or equivalent


Specification ESR-M1C159-A

Removal and Installation

- 1. Set the mode select switch to the 4WD HIGH position.
- 2. Raise and support the vehicle. For additional information, refer to Section 100-02.
- 3. Disconnect the gearmotor encoder assembly harness connectors.



4. Remove the three bolts and the gearmotor encoder assembly.



- 5. Remove the grease from the motor adapter and check for any nicks or burrs. If any damage is found, repair or install a new adapter as necessary.
- 6. To install, reverse the removal procedure.
 - Apply a coat of grease to the new motor adapter.