
MAIN LIGHT SWITCH
FUEL TANK SELECTOR SWITCH
FUEL TANK SELECTOR VALVE
HOT IN RUN OR ACC
HOT IN START OR RUN
HOT AT ALL TIMES
HOT AT ALL TIMES
CENTRAL JUNCTION BOX
FUSE 33 15A
FUSE 45 10A
FUSE 41 10A
FUSE 35 10A
CYLINDER HEAD TEMPERATURE SENSOR
POWERTRAIN CONTROL MODULE
ENGINE COOLANT TEMPERATURE SENSOR (M/T)
AUTOMATIC TRANSMISSION MODULE (A/T)
PARKING BRAKE SWITCH
OVERHEAD CONSOLE
TRIP COMPUTER MODULE
INSTRUMENT CLUSTER
COMPUTER DATA LINES SYSTEM
EXTERIOR LIGHTS SYSTEM
COMPUTER DATA LINES
DEFOGGER SYSTEM
WARNING SYSTEM
TRANSMISSIONS SYSTEM
INTERIOR LIGHTS SYSTEM
ANTI-THEFT SYSTEM
CHARGING SYSTEM
HEADLIGHTS SYSTEM
SUPPLEMENTAL RESTRAINTS SYSTEM
ANTI-LOCK BRAKE SYSTEM
W/O AUXILIARY FUEL TANKS
W/ AUXILIARY FUEL TANKS
FUEL TANK UNIT
FUEL TANK SELECTOR VALVE
SECONDARY FUEL SENDER
PRIMARY FUEL SENDER
BRAKE FLUID LEVEL SWITCH
OIL PRESSURE SWITCH
ABS CONTROL MODULE
SPEED CONTROL SERVO
POWERTRAIN CONTROL MODULE
GAS
DIESEL
Ⓐ EXCURSION
Ⓑ PICKUP
Ⓒ W/O KEYLESS ENTRY
Ⓓ A/T
Ⓔ M/T
153143